

Mojo Bike – Assembly Instructions

Tools Required

- 4mm Hex Key
- 5mm Hex Key
- 15mm open-ended spanner
- Waterproof grease

Unpacking

Congratulations on the purchase of your new Mojo Bike. Remove it from its box, either recycling the packaging or keeping it in tact should you need to pack your bike up in future.

Assembly

Step 1

Apply some grease to the inside of the seat tube and slide the seat post in to the minimum insertion mark. Grease the threads of the seat post bolt and tighten so the post is supported. You will align the seat and tighten the post in a latter step.



Step 2

You are now ready to install the handlebars. Center the handlebars in the clamp and tighten the stem bolts evenly so the handle bars are supported. You will align the handlebars and tighten in a latter step.



Step 3

Inflate the tyres to the recommended pressure. Slide the wheel up evenly into the fork dropouts. Align the lock-tabs with the cut-outs. Tighten the nuts.



Step 4

You are now ready to install the pedals. Grease the pedal threads. Install the right-hand (relative to you when on the bike) pedal by turning it in a clockwise manner. The left-hand (relative to you when on the bike) pedal has a reverse thread. Install it by turning it in a counter-clockwise manner. Tighten the pedals with the open-ended spanner.



Step 5

You can now make your final adjustments to the alignment of the seat and handlebars.

You can now adjust the seat height and angle. Align to the desired position and tighten.

You can now adjust the handlebars. Align to the desired position and tighten ensuring that you tighten the bolts evenly.

You can now cable tie the brake-line along the top tube.

Your now ready for your first ride!

Be sure to check back at www.mojobike.com.au and subscribe to our newsletter to keep up on new models and upgrade parts. You can even join us on Facebook to share an image of your new ride.